

■ オプション(別売)

本製品は下記の別売のオプションを利用することができます。


- グラウンドシート ムーンライト®スクリーン2、4用
フロアとして使用できます。
- ステンレスペグ20、30
- ショックレスペグハンマー
- メッシュアンカー
付属のペグが使用できない河原やガレ場でのタープの固定に
使用します。

■ 仕様


○ 寸法

※図中の単位はcmです。

- ムーンライト®スクリーン 2
#1122742



- ムーンライト®スクリーン 4
#1122741



○ 素材

- 本体: 68デニール・ポリエステル・リップストップ [耐水圧1,500mmウレタン・コーティング、難燃加工]
- ポール: アルミニウム合金

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont·bell

共通取扱説明書

ムーンライト®スクリーン

Moonlight® Shelter

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は、設営が容易で広々とした内部空間を実現した自立式タープです。全面をメッシュにすることもでき優れた通気性を誇ります。

■ 各部の名称



タープ本体



※張り網付き

ペグ: 16本



ペグ収納袋

Aフレーム 2セット




フレーム収納袋

ポール応急補修用パイプ 1本



収納袋 / 取扱説明書(本書)



■ 安全上の注意 必ずお読みください

!

危険

人が死亡または重傷を負う危険が差し迫って生じることが想定される内容です。

- 本製品内や本製品の近くでは、絶対に火気を使用しないでください。火災や一酸化炭素中毒の恐れがあります。
- 出入り口やベンチレーションを常に開け、換気に充分ご注意ください。
- 台風、落雷、強風、豪雨、大雪などの厳しい自然条件の際は、キャンプ場の管理担当者の指示に従い安全な場所に避難してください。
- 河原や河川付近に設営する際は気象条件により突然増水することがあります。設営場所は特に注意してください。

!

警告

場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。


- 本製品を設営される際は、周囲の環境や気象条件などを充分考慮し、安全を確認してください。
- 出入口は風下側を選び設営してください。強風で本製品が飛ぶ恐れがあります。
- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、充分に保護能力が発揮できない恐れがあります。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

!

注意

人が傷害を負ったり物的損害の発生が想定される内容です。

- 稜線上や大木の近く、広い草原では落雷に注意してください。
- キャンプ場やキャンプ許可地以外では使用しないでください。
- 設営地はできるだけ平坦で、危険のない場所を選んでください。
- 使用の際は必ずペグと張り綱で固定してください。砂地や雪上では付属のペグが使用できない場合があります。あらかじめ設営する場所の地面の状態を確認してください。
- 本製品は太陽光線の紫外線により生地が劣化しますので、常設用として使用し続けないでください。
- 硫黄ガスが発生する温泉地等での使用は、生地の劣化を促進させますのでご注意ください。
- 各パーツや付属のペグには鋭利な部分があります。取扱いにご注意ください。
- ポールを伸ばす際は周囲に十分に注意してください。近くに人がいないことを確認してください。
- ポールをタープ本体に取り付ける際はポールの跳ね返りに注意してください。
- 小さいお子さまにポールの組立てや、ペグ打ちの作業をさせないでください。
- タープ本体の生地は防水加工が施されています。外気との温度差が大きいと、結露によって生地の内側の壁面に水滴がつくことがあります。これは水漏れではありません。本製品の換気を行うことで改善することができます。
- ポールを組み立てる際は、奥まで差し込んでください。奥まで差し込まないとポールが破損する恐れがあります。また、指を挟まないようにしてください。
- ショックコードを必要以上に伸ばさないでください。ポールが跳ね返った際、衝撃でポール先端が破損する恐れがあります(右図参照)。
- 濡れたままで長時間他のものや各パーツと一緒に置いておくと色移る恐れがあります。




■ 使用前の点検

- ☐ ポールに亀裂などの破損がないか
- ☐ 生地に破れがないか


■ 使用方法

- **組み立て方法**
新しいタープに慣れるため、実際にフィールドへ出かける前に、必ず試し張りを行ってください。

- ① ポールは、中に通っているショックコード通りにポールをつなぎ合わせる(図A)と自然に組み上がります。ジョイントへのポールの接続は(図B)のように行います。ポールがジョイントに確実に入っていることを確認してください。※ショックコードを必要以上に伸ばさないように注意してください。



- ② ①でつなぎ合わせた2つのAフレームをタープ本体のポール受けにそれぞれ差し込みます(図C)。




- ③ タープ本体頂点部分のフックを上側のポールにかけます(図D)。



④ 下図の①②③の順番でタープ本体をAフレームに固定してください(図E)。

(図E)




⑤ タープ本体の残りのフックをすべてポールにかけます(図F)。

(図F)





⑥ 図Cのポール受けに設けられたペグ用ループをペグで留めます(図G)。
※ペグで留める際は、ペグをこれ以上打ち込めない深さまで、打ち込んでください。
※付属のペグが使用できないガレ場や雪面では別売のメッシュアンカーなどを用いて固定してください。




⑦ タープ本体の張り網は風が吹くことを想定して必ず取り付けてください。8カ所の張り網をペグで固定します(図H)。付属の張り網はランナー(自在金具)がついており、ランナーを通したループをペグにかけて長さを調節します(図I)。なお、このタープにハンマーは付属していません。
※ペグで留める際は、ペグをこれ以上打ち込めない深さまで打ち込んでください。

(図H)



⑧ 必要に応じてマッドスカートのペグループを別売のペグで固定してください(図J)。

(図J)



○ 収納方法

① ペグを抜きます。その際、ペグは必ずペグ用収納袋に入れてください。そのまま収納すると本体生地を傷つけることがあります。


② タープ本体のフックをポールから外してください。

③ ポールの先端をポール受けから外します。その際ポールが跳ね返ると危険ですので、ポールが伸びきるまで手を離さないでください。

④ ジョイントからポールを抜き、ポールの真ん中から折りたたむようにします(図K)。こうすることにより、ショックコード全体に均一にテンションがかかり、ショックコードの寿命を伸ばすことができます。

⑤ タープ本体を収納袋の幅に合わせて畳み、収納します。

(図K)



○ ベンチレーションの開閉方法

天頂部にある4カ所のベンチレーション用の支え(図L)を外側に押し込み(図M)、ベンチレーションを開きます。

(図L)



(図M)




○ 本製品とムーンライト®テント(別売)の接続方法

※簡易的に接続する方法であり、雨風や虫などの侵入を完全に防ぐものではありません。


※【対応テント】ムーンライト®スクリーン2→ムーンライト®テント2 ※2019年以前のモデルには対応していません。
ムーンライト®スクリーン4→ムーンライト®テント4

※ムーンライト®テントの設営方法はムーンライト®テントの取扱説明書を参照してください。


① 本製品のサイドパネルのメッシュジッパーを開きます。本製品の入り口とムーンライト®テントのレインフライを開き、入り口同士を合わせます。本製品とムーンライト®テントの隙間を埋めるために、入り口のジッパーをムーンライト®テントの入口の上端の高さに合うように閉めます。



- ②本製品入り口の本体生地とムーンライト®テントのレインフライを一緒に巻き上げます。
この時、本製品入り口のメッシュは一緒に巻き上げないでください。



- ③巻き上げた入り口のトグルについているループとムーンライト®テントのレインフライのトグルを留めます。




- ④本製品のメッシュを閉じて完成です。



○ 破損時の対応

1. ポール

タープ設営時に強風や豪雪などの理由で本製品のポールが万一破損した際は、右図の通り応急処置をしてください。副木を添えて応急処置をすることもできますが、本製品の付属品であるポール応急補修用パイプを用い応急処置も可能です。



2. タープ本体

生地の破損についてはリペアシート（別売）をご用意しております。

※使用後は修理を依頼してください。販売店もしくは（株）モンベル カスタマー・サービスにお問い合わせください。

■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- 使用後は、泥汚れなどをあらかじめ水洗いし、陰干しして乾燥後に収納してください。汚れたまま、あるいは濡れたまま長時間放置するとカビの発生する可能性があります、また生地も劣化しやすくなります。
- 長期の使用により、タープ本体のはっ水性能（水を弾く力）が低下した場合は別売のはっ水スプレーをご使用ください。
- ドライクリーニングや洗濯機による洗濯はできません。生地を傷める恐れがあります。
- ジッパーの動きが固くなりましたら、別売りのスムーズライダー™やローソクの口を塗ると回復します。
- ポールやペグは汚れを濡れタオルで拭き取った後、機械油を薄く塗っておきます。ポールは接合部にのみ、塗布します。

■ 保管方法

- 本製品を長期間使用せずに保管する場合は、なるべくゆるくたたみ、直射日光の当たらない風通しの良い場所に保管してください。付属の収納袋は、携行性を重視しているため、きつめにたたまないと入らないので使用を避けてください。
- 火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

■ 廃棄方法

- 廃棄方法はお客様の自治体の収集方法に従ってください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ Accessories (Sold separately)

The following accessories are compatible with this product.

● Moonlight Shelter 2,4 Footprint

Use as a floor inside the shelter.

● Stainless Peg 20,30

● Shockless Peg Hammer

● Mesh Anchor


An anchor for use in rocky terrain.

■ Specifications


○ Dimensions

*Units are in centimeters.

○ Moonlight Shelter 2 #1122742



○ Moonlight Shelter 4 #1122741



○ Materials

- Tarp: 68-denier polyester ripstop(urethane coating, water pressure resistant to 1,500mm, flame resistant)
- Poles: aluminum alloy with internal shock cord and socket

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN
<https://www.montbell.com/>

mont-bell

User's Manual

Moonlight Shelter

Moonlight Shelter



Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

■ Description

Enjoy easy setup and a spacious interior with a freestanding design. Pull back the outer side panels to enhance interior air circulation through the mesh panels.

■ Components



1x Pole repair sleeve

Carrying case
User's manual

■ Safety Warnings! Please read carefully.



DANGER!

Under certain conditions, use of this product can result in major injury or death.

- NEVER place a flame source in or near your tent, tarp, or shelter. Injury or death by fire and/or carbon monoxide poisoning is possible.
- Ventilate the tent, tarp, or shelter at all times by keeping ventilators or tent door(s) open.
- Follow campsite instructions for evacuation and safety procedures when encountering harsh weather conditions such as typhoons, lightning, strong winds, heavy rain or snow.
- When selecting a campsite near rivers or river beds please take into consideration that weather conditions can cause rivers to flood suddenly.



WARNING!

Under certain conditions, use of this product can result in injury, death, or property damage.


- When selecting a campsite, check the safety of the surrounding area and be aware of weather conditions.
- When selecting a campsite, place the entrance of the product downwind. Be aware this product can be blown away by strong winds.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.
- Please follow recommended care and storage instructions. Improper care and storage can lead to a decrease in performance.



CAUTION!

Under certain conditions, use of this product can result in injury or property damage.

- Be careful of lightning in the mountains when close to trees or in open fields.
- Only pitch tents, tarps, or shelters in areas designated for camping.
- Choose a campsite free of danger and as level as possible.
- Use pegs and guylines to stake your tent, tarp, or shelter at all times. Pegs may not be suitable for all ground conditions, such as sand or snow. Before pitching the tent, check ground conditions to see if staking pegs is possible.
- Ultraviolet rays from the sun may damage the product's fabric. Leaving the product outside for extended periods of time may cause the product to deteriorate rapidly.
- Sulfur gas from natural hot springs can also shorten the product's lifespan.
- Be careful when handling pegs or parts included in the product as they can have sharp edges.
- When assembling the poles, make sure the area is clear and be careful of other people in the area.
- When attaching poles to the tent, tarp, or shelter, be careful of recoil.
- Do NOT allow children to assemble the poles or stake pegs.
- The tarp has a waterproof urethane coating. Depending on the difference in temperature and humidity, water may condense on the inside of the tarp. This does not mean the tarp is leaking. Condensation can be prevented with adequate ventilation.
- When assembling the poles, make sure all sections are fully inserted and be careful of pinching your fingers in between pole sections.
- Do NOT pull the shock cord more than necessary. Recoil can damage poles as seen in the figure to the right.
- Colors can transfer when allowed to sit for an extended period of time while wet.



■ Prior to use, inspect this product for: Stop using immediately if you notice any irregularities.

- Cracks or damage to poles.
- Tears or damage to fabric.


■ Directions

○ Pitching the shelter

Before using the product for the first time, practice pitching at home to familiarize yourself with the product and its features.


- 1 Assemble the poles (Fig. A). Insert the poles into the sockets to make the frame (Fig. B). Make sure the poles are securely inserted into the sockets.

*Do NOT pull the shock cord more than necessary.



- 2 Insert the pole legs on the two completed frames into the 8 grommets on the tarp (Fig. C).

(Fig. C)




- 3 Secure the clip on the top of the tarp to the uppermost pole (Fig. D).

(Fig. D)




- ④ In the order ①-②-③ as shown below, attach the clip to the pole ①, attach the semi-circular clip to the pole joint ②, and hang the loop to the pole end ③ (Fig. E).

(Fig. E)



- ⑤ Attach the remaining clips to the poles (Fig. F).


(Fig. F)



- ⑥ Stake down the shelter using the peg loops at the corners (Fig. G).

*Stake pegs as deep as possible.



*When staking the shelter in rocky or snowy conditions, consider using the Mesh Anchor or Snow Anchor (both sold separately).



- ⑦ Always secure the shelter with guylines to be prepared for windy conditions. There are 8 guylines on the shelter that need to be staked down with pegs (Fig. H). Adjust the position of the cord runner to tension the guyline (Fig. I). This shelter does NOT include a hammer for staking the pegs.


*Stake pegs as deep as possible.

(Fig. H)



- ⑧ If necessary, stake down the mud flap with additional pegs (sold separately) at the points shown in Fig. J.

(Fig. J)



○ Taking down the shelter

- ① Pull up all the pegs. Put pegs in their stuff sack. Pegs should not have direct contact with the tarp, as the edges could potentially damage the fabric.


- ② Unclip the tarp's clips from the poles.

- ③ Remove the ends of the poles from the grommets. Firmly hold the poles until the poles are no longer at tension as there is a risk of injury due to recoil.

- ④ When taking apart the poles, remove the pole sections from the socket and then break down the poles starting at the middle (Fig. K). This extends the life of the shock cord by placing an even amount of tension over the entire length of the cord.

- ⑤ Fold the tarp into the same width as the carrying case for easier storage.

(Fig. K)



○ Opening the ventilator

Take the four tabs located (Fig. L) at the ceiling's apex (Fig. L), and push outward (Fig. M) to open the ventilators.



(Fig. M)



○ Connecting to a Moonlight Tent (sold separately)

*Connection does NOT provide full integration, and is NOT completely rain, wind, or insect-proof.


*Compatible models: Moonlight Shelter 2→Moonlight Tent 2

Moonlight Shelter 4→Moonlight Tent 4


*NOT compatible with models made in 2019 or earlier.

*For instructions on pitching the Moonlight Tent, see the tent's user's manual.


- ① Open the Moonlight Shelter's side panels and the Moonlight Tent's rainfly. Align the entrance of the tent with the side entrance of the shelter. To eliminate the space in between, close the side panel's zipper down to the height where the rainfly's zipper starts.




- ② Take the shelter's side panel and the tent's rainfly and roll them up together.
Do NOT roll up with the mesh.



- ③ Secure the side panel and rainfly using the rainfly's toggle and the side panel's loop.




- ④ Setup complete.



Emergency repair

1. Pole

In case strong wind or heavy snow breaks a pole, temporarily fix the pole as shown on the right. Although it is possible to use a splint to do the job, we recommend using the pole repair sleeve that is included in this product.



2. Tarp

If the tarp fabric is damaged or tears, temporarily apply the Repair Sheet (sold separately).

*Afterwards, contact the store of original purchase or Montbell Customer Service for information on permanent repair.

Care

Improper care and storage can shorten the lifespan of this product.

To extend the lifespan of this product, please follow the recommendations below.

- Wash away stains and soiling with water. Avoid direct sunlight and allow to air dry in a cool well-ventilated area. If stored wet or soiled, mold can grow and the fabric can start to prematurely deteriorate.
- Over time the product's water repellent treatment will deteriorate. To restore the product's water repellent abilities, reapply a water repellent spray (sold separately).
- Do NOT dry clean or wash in washing machine. This can damage the product's fabric.
- If zipper movement becomes stiff, use the Smooth Slider (sold separately) or candle wax to restore functionality.
- Use a damp cloth to clean poles and pegs. Afterwards apply a silicone lubricant. For poles, only lubricate the joints.

Storage

- When storing for an extended period of time, store loosely in a well-ventilated, cool, dry place out of direct sunlight. Shelters are not designed to be stored long term in their carrying cases that should only be used for transporting the shelter.
- To prevent deformation and damage to the tarp, do NOT store near heat sources.

Disposal

- Please follow local regulations regarding waste disposal.

Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.